





SunPump™ L-Foot Bracket.



NOTES: Dimensions shown are inches and (millimeters).

Recommend attaching L and U-foot brackets to thermal panels on the ground, then use them on the roof as a drilling template for accuracy and speed.

PROJECT: **SunPump Panel**
solarisgeothermal@gmail.com

TITLE: **L-FOOT BRACKET**





DWG. No. **1** REV. **A**

DRAWN BY: B. GRAY ©

Sunpump

REVISION DATE: April 23, 2015

SunPump™ U-Foot Bracket.



NOTES: Dimensions shown are inches and (millimeters).
 Recommend attaching L and U-foot brackets to thermal panels on the ground, then use them on the roof as a drilling template for accuracy and speed.

PROJECT: SunPump Panel	TITLE: U-FOOT BRACKET		DWG. No. 2	REV. A
solarisgeothermal@gmail.com	Sunpump		REVISION DATE: April 23, 2015	
DRAWN BY: B. GRAY ©				